



Start-Up Notice!

Overview

If you're using the Humminbird® control head for GPS navigation only, such as with the Vehicle Mount or the ATV Handlebar mount, it is important to turn off the sonar at start-up. When you're ready to fish, turn on the sonar.

Navigation Start-Up (GPS only)

To use your Humminbird in navigation mode only, **without a transducer attached** to the control head, the sonar should be disabled.

1. Press the **ⓘ** POWER/LIGHT key. As soon as the Title screen is displayed, press the MENU key.
2. Start-Up Options Menu: Press the UP Cursor key to choose Normal, and press the RIGHT Cursor key to select it.

***NOTE:** If a transducer is not connected and you wait too long to select a Start-Up Option, the system will start Demonstration mode. Demonstration mode cannot be used for operation.*

3. Follow the on-screen instructions.
4. When the first view displays on the screen, press the MENU key twice to open the Main Menu.
5. Press the RIGHT Cursor key until the Setup tab is selected. Press the DOWN Cursor key to select Sonar.

***NOTE:** This feature may appear as either Sonar or Local Sonar, depending on your control head model.*

6. Press the LEFT Cursor key to change the Sonar menu option to Off. Press the EXIT key twice to start operating with GPS only.

Sonar Start-Up

To use your Humminbird control head for fishing, the sonar must be enabled.

1. Connect the transducer to the control head. See the installation guide for details.
2. Press the **ⓘ** POWER/LIGHT key. The unit will start Normal mode automatically.
3. Press the MENU key twice. Press the RIGHT Cursor key until the Setup tab is selected. Press the DOWN Cursor key to select Sonar.

***NOTE:** This feature may appear as either Sonar or Local Sonar, depending on your control head model.*

4. Press the RIGHT Cursor key to change the Sonar menu option to On. Press the EXIT key twice. The Sonar views will be added to the view rotation, and the fishfinder is ready for operation.

Contact Humminbird

Visit our Web site at humminbird.com or call Customer Service at 1-800-633-1468.